

# STEP-BY-STEP GUIDE PLUG&CHARGE

PLUG&CHARGE is a new authentication method in which a charging session starts automatically once the e-vehicle is connected to the charging point. It is no longer required to authorise the transaction using the charging card, app or a QR code. The transfer of billing data and bidirectional communication takes place exclusively via the vehicle's charging plug.

## How the PLUG&CHARGE service works:

